



BERGEON

Depuis 1791

Tasseaux à chasser

Sans trou.



Einpresstempel

Ungebohrt.



Driving punches

Undrilled.

Tases para embutir

Sin agujero.

∅ mm	N°	gr.	Pce Fr.
3.00	6200-03	5.80	
6.00	6200-04	7.00	
9.00	6200-05	9.00	

Poinçon à centrer

Zentrierspitze

Centring bit

Punzón para centrar



N° 6200-06	6.50 gr.	Pce Fr.
------------	----------	---------

Enclume

Sans trou, ∅ 25 mm.

Amboss

Ungebohrt, ∅ 25 mm.

Stake

Undrilled, ∅ 25 mm.

Tas

Sin agujero, ∅ 25 mm.



N° 6200-07	114 gr.	Pce Fr.
------------	---------	---------

Enclume percée

Amboss, gebohrt

Stake, drilled

Tas taladrado



Enclume Amboss Stake Tas ∅ mm	Trou Loch Hole Agujero ∅ mm	N°	gr.	Pce Fr.
8.00	3.00	6200-08	22.00	
10.00	5.00	6200-09	27.00	
16.00	8.00	6200-10	43.00	
30.00	10.00	6200-11	145.00	

Enclume à centrer

Zentrieramboss

Centring stake

Tas para centrar



Enclume Amboss Stake Tas ∅ mm	Pointe Spitze Point Punta ∅ mm	N°	gr.	Pce Fr.
16.00	4.00	* 6200-12	47.00	
16.00	9.00	6200-13	45.00	