








N°	Code	HV	 %	 %	A	B	←→ mm	↕ mm
7024-1	<b>B</b> <sub>JET</sub>	230	65	35	0.10	0.15	120	10
7025-1	<b>B</b> <sub>XEL</sub>	280	95	5	0.10	0.15	120	10
7026-1	<b>B</b> <sub>C<sub>2</sub></sub>	230	80	20	0.10	0.15	120	10
7027-1	<b>B</b> <sub>VOX</sub>	700	0	100	0.10	0.15	120	10
7028-1	<b>B</b> <sub>*</sub>	290	100	0	0.10	0.15	120	10



N°	Code	HV	 %	 %	A	B	←→ mm	↕ mm
7024-2	<b>B</b> <sub>JET</sub>	230	65	35	0.05	0.15	120	10
7025-2	<b>B</b> <sub>XEL</sub>	280	95	5	0.05	0.15	120	10
7026-2	<b>B</b> <sub>C<sub>2</sub></sub>	230	80	20	0.05	0.15	120	10
7027-2	<b>B</b> <sub>VOX</sub>	700	0	100	0.05	0.15	120	10
7028-2	<b>B</b> <sub>*</sub>	290	100	100	0.05	0.15	120	10



N°	Code	HV	 %	 %	A	B	←→ mm	↕ mm
7027-PM-2A	<b>B</b> <sub>VOX</sub>	700	0	100	0.05	1.65	120	10