







N°	Code	HV	 %	 %	A	B	←→ mm	↕ mm
7024-4	B _{JET}	230	65	35	0.10	0.10	110	10
7025-4	B _{XEL}	280	95	5	0.10	0.10	110	10
7026-4	B _{c₂}	230	80	20	0.10	0.10	110	10
7027-4	B _{VOX}	700	0	100	0.10	0.10	110	10
7028-4	B _★	290	100	0	0.10	0.10	110	10



N°	Code	HV	 %	 %	A	B	←→ mm	↕ mm
7024-5	B _{JET}	230	65	35	0.06	0.10	110	10
7025-5	B _{XEL}	280	95	5	0.06	0.10	110	10
7026-5	B _{c₂}	230	80	20	0.06	0.10	110	10
7027-5	B _{VOX}	700	0	100	0.06	0.10	110	10
7028-5	B _★	290	100	0	0.06	0.10	110	10