







N°	Code	HV	 %	 %	A	B	←→ mm	↕ mm
7024-4	<b>B</b> <sub>JET</sub>	230	65	35	0.10	0.10	110	10
7025-4	<b>B</b> <sub>XEL</sub>	280	95	5	0.10	0.10	110	10
7026-4	<b>B</b> <sub>c:</sub>	230	80	20	0.10	0.10	110	10
7027-4	<b>B</b> <sub>VOX</sub>	700	0	100	0.10	0.10	110	10
7028-4	<b>B</b> <sub>*</sub>	290	100	0	0.10	0.10	110	10



N°	Code	HV	 %	 %	A	B	←→ mm	↕ mm
7024-5	<b>B</b> <sub>JET</sub>	230	65	35	0.06	0.10	110	10
7025-5	<b>B</b> <sub>XEL</sub>	280	95	5	0.06	0.10	110	10
7026-5	<b>B</b> <sub>c:</sub>	230	80	20	0.06	0.10	110	10
7027-5	<b>B</b> <sub>VOX</sub>	700	0	100	0.06	0.10	110	10
7028-5	<b>B</b> <sub>*</sub>	290	100	0	0.06	0.10	110	10