






N°	Code	HV	 %	 %	A	B	←→  mm	↕ mm
7024-AA	<b>B</b> <sub>JET</sub>	230	65	35	0.30	0.25	125	10
7025-AA	<b>B</b> <sub>XEL</sub>	280	95	5	0.30	0.25	125	10
7026-AA	<b>B</b> <sub>c<sub>2</sub></sub>	230	80	20	0.30	0.25	125	10
7027-AA	<b>B</b> <sub>VOX</sub>	700	0	100	0.30	0.25	125	10
7028-AA	<b>B</b> <sub>*</sub>	290	100	0	0.30	0.25	125	10



N°	Code	HV	 %	 %	A	B	←→  mm	↕ mm
7026-F	<b>B</b> <sub>c<sub>2</sub></sub>	230	80	20	0.08	1.70	120	10
7027-F	<b>B</b> <sub>VOX</sub>	700	0	100	0.08	1.70	120	10
7027-PM-F	<b>B</b> <sub>VOX</sub>	700	0	100	0.08	1.70	120	10
7028-F	<b>B</b> <sub>*</sub>	290	100	0	0.08	1.70	120	10