



Specifications:

Size	130*120*570 mm
Lens Diameter	110 mm
Magnification	2X/4X
Material	Acrylic Lens + Metal Hose + Plastic
Weight	750g
LED	18 pcs
Power	Under 5V 1A
Lumen	200 LM
Use	Clip & Desktop

How To Use:

1. This magnifying lamp is easily detachable into either a desktop magnifier with a base or a clip magnifier that will easily fasten onto the side of your table.
2. If you want to turn on the light, plug the USB end of the cable into a USB adapter, power bank, computer, etc.
3. Three different brightness by touch the switch you can choose the most comfortable brightness.

Accessories:

1. Cleaning Cloth
2. Manual
3. Micro USB Cable

LED Lights:



The LED lamp comes with three adjustable brightness levels.

1. Turn ON: touch the switch once (minium brightness)
2. Touch the switch again to medium brightness (second setting)
3. Touch the switch again to maxium brightness (third setting)
4. Touch the switch fourth time to turn off the light

Warnings:



1. Do not place the magnifying glass in direct sunlight. Reflection of direct sunlight by the glass could cause a fire.
2. Wipe the lens with the included cleaning cloth to prevent scratching.
3. Never use detergent, gasoline, furniture polish, paint thinner, or other chemicals to clean any part of the magnifying glass, as it will damage the lens.
4. The unit is not waterproof and should never be used in wet conditions.